

XR 25



ACTIA 

CONTENTS

	Page
General	2
Description of the test box.....	3
Description of wiring harness.....	4
Connection to vehicle	5-6
Self-testing the test box	7

MULTIMETER

Frequency generator	9
Voltmeter	10
Pulse sensor	10
Continuity sensor	10
Examples of display.....	11

FAULT FINDING

How to use	13
Additional tests	14
Examples of display	15-16
Using the memory in a road test	17
Particular cases of vehicles fitted with M type gearbox..... (3 speed) (Load potentiometer adjustment)	18
Connecting to a diagnostic bay	19

APPENDIX

Abbreviations and signs used	21
Possible operating incidents	22
Main wiring diagram	23
After-Sales service	24

General

The XIR 25 test box is designed to analyse diagnostic information emitted by the computers fitted to the vehicle. It enables the result to be clearly displayed for diagnosing the electronic system rapidly and precisely in-situ.

The test box offers the user three different ways of operating :

- Diagnostic function : analyses and displays data.
- Multimeter functions : voltmeter
continuity tester
pulse detector and generator.
- Memory function : enables the context in which the incident occurred to be stored and displayed.

The functions are selected on a 16 key keyboard.

The data are displayed by 2 types of display :

- Bar graphs (left-hand side of apparatus).
- By a four-digit liquid crystal display (at the top of the apparatus).

This apparatus can be used both with the vehicle stationary and in a road test.

It is fed directly by the vehicle's battery :


- Either by means of the same cable connected to the diagnostic socket.
- Or by a cable connected directly to the battery (supplied with the apparatus).

The functions necessary for interpreting the diagnostic data are contained in a memory cassette.

This cassette 9 is interchangeable so as to allow the test programme to be updated in accordance with product developments and tests performed on new products available in the network. Each new cassette cancels and supersedes the preceding one.


The ISO adaptor 12 enables the operation of the test box to be rendered compatible with certain diagnostic transmission features of the new computers such as : Bendix ABS, Air conditioning, Memorised seats, Automatic transmission.

Description




- | | |
|------------------------------------|-------------------------------------|
| ① Result display | ⑧ Continuity or insulation check |
| ② Test card corresponding to test | ⑨ Programme memory cassette |
| ③ Magnetic mounting | ⑩ Cassette connection warning light |
| ④ Selector keyboard | ⑪ Numerical value display |
| ⑤ Lights showing function selected | ⑫ ISO adaptor |
| ⑥ Pulse generator output | ⑬ Diagnostic socket connection |
| ⑦ Pulse sensor / voltmeter input | ⑭ Diagnostic bay connection |

Wiring harness




Connection cable for vehicle with standardised diagnostic socket (battery supply included)

Ref ACTIA : 911 012




Connection cable for vehicle without standard diagnostic socket

Ref ACTIA : 911 013




Cable for adjusting potentiometer of automatic gearbox (M type 3 speed) load potentiometer

Ref ACTIA : 911 014



Extension cable

Ref ACTIA : 463 007




Measuring leads and probe tips

Ref ACTIA : 450 040, 450 041, 403 005, 403 006

Connection to vehicle

For fault finding :


I) Vehicle equipped with diagnostic socket



Do not confuse this socket with the socket which does not have a foolproofing device and is used to check the ignition.

II) Vehicle without diagnostic socket

The connection below is for a vehicle equipped with a 3-speed gearbox (M type).



- (A) Identify the computer.
- (B) Disconnect the warning light feed.
- (C) Connect the green terminal as shown.

Note : The yellow terminal is not used.

Connection to vehicle (continued)

For measuring

- Voltmeter.
- Continuity detector.
- Pulse sensor.
- Frequency generator.


Vehicle with diagnostic socket : connect as in I cable



Vehicle without diagnostic socket : connect as in II cable
(The green and yellow terminals are not used).



For measuring, use cables X connecting them either at



TEST TYPE	HARNESS TO USE depending on vehicle		KEYS TO USE	PAGE
	WITH diagnostic socket	WITHOUT diagnostic socket		
FAULT FINDING			and ? ?	13
MULTIMETER MEASUREMENTS	and	and	Voltmeter Continuity detector Generator Pulse detector	10 10 9 10
CHECKING and ADJUSTING the potentiometer			and	18

Self-test

Each time it is switched on, the test box tests itself automatically.

In order to avoid incorrect fault finding, it is important to test all the displays visually as occurs when the test box is switched on.

Each time the test box is switched on :

- 1) All the displays on central display **11** should illuminate.
- 2) The bar graphs illuminate one after another separately.
- 3) All the figures from 0 to 9 run through on the central display.
- 4) "r 25 "is displayed to indicate the end of this automatic test.

If this phase does not occur, check warning light **10**

If it is not illuminated, the cassette is not in the correct position.

Note : The self-test function may be suspended by pressing any of the keys on the keyboard.

MULTIMETER

Multimeter connections

In order to use the test box for one of the multimeter functions, it must be connected to the battery by means of cable **U** or **V** (see page 6).

The cords and probe tips **X** enable data to be input or output.

Frequency generator

This function is selected by pressing key **G** followed by a number allocated to each frequency desired. The output signal is available on the female terminal "G".

Currently, 9 frequencies are programmed :

0 = 2 Hz	1 = 50 Hz	2 = 100 Hz	3 = 150 Hz	4 = 200 Hz
5 = 250 Hz	6 = 300 Hz	7 = 350 Hz	8 = 400 Hz	

The central display indicates the number selected.

This function generates square pulses of maximum amplitude equal to the battery voltage.

This output is protected against short circuits or connecting to the battery + terminal.

Examples of use :

- Simulating vehicle speed, checking ignition power module, etc....

Voltmeter

This function is selected by pressing key **V**. The female terminal "Vin" enables data to be input. The test box feed earth serves as a reference. Only continuous voltage can be measured. The input resistance is 1 MO and the tolerance is $\pm 4\%$ from 0 to 25 volts (do not connect to secondary HT winding).

Pulse detector

This function is selected by pressing key **G**. The signal is input via the female "Vin" terminal **7**. The central display indicates the duration of the positive pulse in milliseconds. Measurements possible between 1 and 1999 ms with 5% accuracy. The input resistance is 1 MO and the trigger threshold for the measurement is 2 volts ± 0.5 .

Example of use :

- Checking idling speed regulating valve, etc.

Continuity detector

This function is selected by pressing key **C**. Information is input via the " Ω " female terminals **8**. They are protected against earthing or connection to + 12 volts. The component to be tested must be electrically disconnected and must not be connected to the vehicle's earth.

Example of use :

Checking relay coil continuity.

Copy function


















This function is selected by pressing keys **✱** and **✱** simultaneously.

It enables the top or bottom condition which may be present on one of the 8 terminals of the diagnostic socket to be displayed on the bar graphs and their voltage levels to be detected (change of state level equal to 5 volts).

Example of use :

Checking whether one of the terminals or harness on the vehicle's diagnostic socket has been accidentally earthed.

Multimeter displays


FUNCTION	KEY	DISPLAY
Voltmeter Voltage 0 volt Voltage 14 volts		 
Frequency generator Frequency selected 50 Hz Frequency selected 350 Hz	  	 
Pulse detector Duration measured 125 ms		
Copy The top levels are on the left-hand side The lower levels are on the right-hand side	 	
Continuity detector If resistance less than 1 K Ω If resistance greater than 1 K Ω		  

FAULT FINDING

To use the test box for this function, it must be connected to the vehicle by means of cable **U** or **V** (see page 4).

Slide card **2** corresponding to the computer to be analysed in the magnetic mounting opposite the bar graphs (all the possible tests are indicated there).

Position the selector on the ISO adaptor **12** as required (specified on the card and page 15).

Ensure that the warning light  on the ISO adaptor is extinguished.

Press key **D** followed by the two code numbers given on the diagnostic card corresponding to the product tested.

Example : **D 0 3** for injection.

READING THE RESULTS :

The central display **11** indicates the message corresponding to the product selected if the diagnostic grid has been recognised, followed by a figure representing the computer identity number.

If nothing is displayed, the test box does not recognise the computer. Horizontal lines indicate that fault finding is not being emitted or that a cassette is out of date.

If the grid is recognised, the bar graph on the top right-hand side is permanently illuminated.


Extinguished bar graphs indicate data is absent.

Flashing bar graphs indicate transitory incidents stored in the computer.

ADDITIONAL TESTS :





























Additional tests are intended to provide information regarding the different parameters of the engine.

The list of parameters measured is indicated on the test card for the computer tested.

To obtain them, just press the  key followed by a number corresponding to the type of parameter selected.









Example:   

Diagnostic displays

TEST TYPE	Position of 12	KEYS	DISPLAY
3-speed automatic transmission (type M) Erase memory by switching off vehicle's ignition	Not used	  	
Cruise control (Bendix) Erase memory by switching off vehicle's ignition	Not used	  	
Injection computer Erase memory by disconnecting battery	Not used	  	
4-speed automatic transmission (type AR4) Erase memory via XR 25 test box	S4	  	
Bendix ABR Erase memory via XR 25 test box	S5	  	
Memorised electric seat Erase memory via XR 25 test box	S6 or S7	  	
Regulated air conditioning Erase memory via XR 25 test box	S8	  	


Note: An incident stored in the computer (but not displayed when the test is performed) causes the bar graph in question to flash regularly.

Examples of displays

<p>Check the test box feed and that cassette is to specification</p>	
<p>Test box waiting for diagnostic messages to be emitted : no readings possible</p>	
<p>Waiting for action on keyboard</p>	
<p>Function requested by key does not exist in computer tested</p>	
<p>Measurement requested is possible but value is zero</p>	
<p>Computer memory being erased</p>	
<p>Test requested being performed</p>	
<p>Diagnostic bay connected to test box (series connection)</p>	

Storing in memory


This enables the context in which the incident occurs to be displayed by storing the results from the computer tested.

These results are displayed by the bar graphs and by pressing the  key followed by two numbers, the list of which is to be found on each diagnostic card.

Using the XR 25 memory

The memory is controlled when the engine is running and after the computer has been selected (for example DO3 for an injection computer).


Store request :

When incident occurs, to store ----> press key 

Special case (first generation injection computers) :

These computers are characterised by no diagnostic display if the defect is not permanent (displayed by horizontal lines on the test box display) when the engine is running.

Store request :

Engine running, press key  **before** setting up conditions for reproducing incident.

Comment : On this type of computer, when the engine is running and there is no incident, an incident must be created to read the data.
(for example : disconnect the air temperature sensor).

Memory loss

The memory is lost by pressing the keyboard function keys or by disconnecting the test box feed.

Adjusting the potentiometer

This function is selected in order to adjust the position of the load sensor for type M automatic transmission (3-speed).

For this adjustment, even if the vehicle has a diagnostic socket, the test box must be connected by cable **W**

Press keys **V** and **1**

- A** Identify the throttle potentiometer.
- B** Disconnect the 3-way connector.
- C** Connect the 3-way connector to cable **W**

Switch on the ignition and press the accelerator pedal down completely.


READING OFF THE RESULTS :

A figure between 0 and 3 should be read off on the central display **11** (0 being the optimum value).

If this figure is above 3 :

- adjust the potentiometer so that 0 appears on the central display.

(which corresponds to an alignment of the two bar graphs on the test box).



Connection to diagnostic bay

Only for **XR25S**

The new version of the **XR25S** test box enables direct connection to a diagnostic bay without the intermediary of an external serie connection interface (ILS) as previously.

The cable for connection to the bay is connected at **14**

As soon as the connection has been made, the test box self-tests the series connection.


The results of this self-test are displayed on the bar graphs.

If one or more bar graphs are illuminated on the right-hand side, this indicates and operating incident on the connection.


Different types of connection are possible by placing the switches located on the rear of the apparatus in the positions shown below.

REAR OF XR25S TEST BOX


SOURIAU
type bay




TECALEMIT type
SOURIAU Bay



SAGEM
Bay (TXE)



RS232C type output



APPENDIX

Abbreviations

AC	Air conditioning	EV	Solenoid valve
ALIM	Feed	EVDA	Solenoid valve
APC	Plus after ignition	EVM	Modulating solenoid valve
APP	Press	GMV	Engine fan assembly
ARd	Rear right-hand	G1 *	Press keys G, 1, *
ARG	Rear left-hand	INFO	Data
ATMO	Normally aspirated	MPA	Ignition power module
AUTO	Automatic	M	Incorrect
AVd	Front right-hand	N	Neutral
AVG	Front left-hand	P	Park
B	Good	PF	Full load
CAPT	Sensor	PG	Full load
CC	Short-circuit	PL	No load
CIRC	Circuit	POT	Potentiometer
CLIQ	Pinking	PRESS	Pressure
CLIMAT	Air conditioning	RAP	Ratio
CO	Open circuit	RCO	Cyclic opening ratio
CORRECT	Correction	RES	Restriction
CONS	Reference	T.A	Automatic transmission
DEF	Incident	TEMP	Temperature
DEM	Starter	TENS	Voltage (battery)
EGR	Gas regulating solenoid valve	VIT	Speed
EL	Solenoid valve	V.MIXAGE	Mixer flap

Signs used

SIGNS USED ON THE CARDS




Bar graph illuminated : indicates data present




Action must be taken (indicated on diagnostic card).




If bar graph illuminated, refer to corresponding text on diagnostic card (indicates data present).



Bar graph extinguished.



Bar graph illuminated on left-hand side : see left-hand text on card.



Bar graph illuminated on right-hand side : see text on right-hand side of card

G1 *

Action requested by test box (for example memorised seat)

G13 *

End of test request : takes computer out of diagnostic mode.

G0 *

Erasure of computer's internal memory.

Incidents

Before returning the test box for repairs, you must ensure that the operating incident is not due to incorrect use.

A- Nothing illuminates

- Check if vehicle ignition on.
- Check battery voltage.
- Check continuity of cables **U** and **T** (see page 23).

B- No self-test

- Check that warning light **10** is illuminated.
If extinguished, then check position of cassette and condition of its terminals.

C- " C xx " displayed (xx being a figure) :

- Faulty cassette.

D- Warning light on ISO adaptor **12** illuminated :

- Disconnect then reconnect diagnostic socket.
If light stays illuminated, check test box harness to diagnostic socket.

E- Bar graph display unsteady or erratic (engine running) :

- Check that test box and its feed harness are not too close to a high tension source such as the spark plug leads, distributor, ignition coil.

F- Results blocked (readings do not change) :

- Check that the test box memory has not been requested by accidentally pressing key **0**
If it has, the last bar graph on the bottom right-hand side will be illuminated. (See page 17 : loss of memory)
- Otherwise see E-

G- Keys press but nothing happens :


- See E-

Note : In cases E-F-G, the test box may have to be disconnected then reconnected to unblock it (cut test box feed).

Wiring diagram

CABLE **U**

If there is no fault finding or feed to the test box, check the continuity of the cable connections.



1	←	Green	→	5
2	←	Black	→	24
4	←	Grey	→	2
5	←	Pink	→	6
6	←	Red	→	11
7	←	Yellow	→	1
8	←	Brown	→	7
9	←	White/green	→	3
10	←	White	→	4
11	←	White/brown	→	8
12	←	Blue	→	9

After-Sales Service

WARRANTY :

The XR25 test box comprises :

- An electric sub-assembly (test box, computer, cassette and ISO adaptor).
- A cable sub-assembly.
- A documentation sub-assembly (cards and notes).

The warranty only applies to the electronic sub-assembly and within the restrictions of ACTIA's liability as set out on the warranty certificate attached to the test box.

The duration of the warranty granted is 1 year for parts and labour inclusive. It starts on the date ACTIA receives the warranty coupon, and this date cannot exceed the expedition date of the test box as indicated on the certificate + 6 months.

ACTIA

4 , Chemin de Pouvoirville
BP 4215

31432 TOULOUSE CEDEX 04
(FRANCE)

tél: 61.17.61.61

télécopie : 61.55.42.31

Contact : Network Standards Swindon
for further information.

XR 25



XR 25

1-10
11-20

1-9
0 * #

V
G
D

Volts
Ω
Diag

XR 25
ACTIA
CODE

XR 25
ACTIA
CODE

